

Can you remember and copy the ever-increasing random flashing light and sound sequence? It's a challenge that will test your memory and reactions.

INSTRUCTIONS FOR USE:

- INSTRUCTIONS FOR USE:

 1. Turn the Memory Maze on by sliding the switch to the ON position.

 2. Memory Maze will start with one random step. Follow that step.
 Memory Maze will then repeat the first step and then add the second step.
 Each time you repeat Memory Maze's steps correctly, it adds another to the sequence. Follow 15 steps correctly to wind. Bet it wrong and Memory Maze will give you a second chance to get it right before having to start over.

 3. If no button is pushed within 15 seconds, Memory Maze will automatically shut off. To start again, slide the switch to OFF and then ON again. When not in use, slide the switch to the OFF position to conserve battery life.

BASE OF UNIT